

# AMERICAN CHANGER & HOFFMAN MINT



*"We're Changing The Industry"*

1400 N.W. 65<sup>th</sup> Place Fort Lauderdale, Florida 33309

Tel: 954-917-3009 ♦ Fax: 954-917-3079

[www.americanchanger.com](http://www.americanchanger.com)

[www.hoffmanmint.com](http://www.hoffmanmint.com)

Toll Free: 800-741-9840

Toll Free: 800-227-5813



## New Marquee Installation Guide (Super Universal Board)

1. Turn off the machine. Unplug the machine from the outlet and disconnect the original marquee from main board.



Marquee will be connected here.

2. Remove the original marquee from the cabinet. Four screws hold it to the top of the cabinet. Be sure to pull the marquee harness completely through the hole in the top of the cabinet when removing the marquee.
3. Remove new marquee from plastic wrap. Run marquee wire through the hole in the top of the cabinet and screw marquee in place.

4. A small harness was shipped with the marquee. Connect the harness to the board.



Marquee to Super Universal Board harness



Harness will be connected here.

5. Connect the harness that was connected to the main board in the previous step to the marquee harness. Tie up excess wire in the same fashion as the original marquee. Finally plug the machine back into the outlet and turn on the board.